



Always start stitching between the marked holes when assembling parts 1,2,3 and 4,5,6.

We used 5-6 oz (~ 2 mm) vegetable tanned leather.
We strongly advise writing each part's number on its back.

