




PRINTING INSTRUCTION

1. File > Print
2. Click on “Page Setup” button make sure your paper size is set to the paper size that you will print and Scale at 100%
3. In “Pages Sizing & Handling” click on “Size” button and select “Actual size”



IMPORTANT NOTE:

- **ADOBE ACROBAT READER (FREE SOFTWARE)** is recommended to open and print the patterns

link for free download

<https://get.adobe.com/reader>



CraftsmanGus : Pattern

Simple Messenger Bag : Pillow M

Mss S01 #4mm.

Main Body : Front & Back / Layout







1.8 mm. REC (max)




X 1

Belt Strap on flap

Belt Buckle area on body

CraftsmanGus : Pattern
D-Ring Holder
1.8 mm. REC





CraftsmanGus : Pattern

Simple Messenger Bag : Pillow M





Mss S01 #4mm.

Main Body : Front & Back / Layout

1.8 mm. REC

X 1

* Can manage to make 2 piece combined (stitch) together.



Overlapping area of the gusset. / (bottom, if use 2 pieces of leather)

