



PRINTING INSTRUCTION

1. File > Print
2. Click on “Page Setup” button make sure your paper size is set to the paper size that you will print and Scale at 100%
3. In “Pages Sizing & Handling” click on “Size” button and select “Actual size”

The image shows two screenshots of software dialog boxes with red callout boxes and arrows providing instructions.

Print Dialog Box:

- Printer:** FUJII XEROX DocuPrint CM215 fw...
- Copies:** 1
- Pages to Print:** All (selected), Current page, Pages 1 - 3
- Page Sizing & Handling:**
 - Size:** Actual size (selected), Fit, Shrink oversized pages, Custom Scale: 100 %
 - Orientation:** Auto portrait/landscape (selected), Portrait, Landscape
- Buttons:** Page Setup..., Printer...

Annotations for Print Dialog:

- Select Actual size:** Points to the "Actual size" radio button in the "Page Sizing & Handling" section.
- Set the paper size:** Points to the "Page Setup..." button.

Page Setup Dialog Box:

- Settings:** Page Attributes
- Format For:** Any Printer
- Paper Size:** A4 (selected), 210 by 297 mm
- Orientation:** Portrait (selected), Landscape
- Scale:** 100 %
- Buttons:** Cancel, OK

Annotations for Page Setup Dialog:


- Select the paper size:** Points to the "A4" dropdown menu.
- Scale 100%:** Points to the "100" value in the "Scale" field.

IMPORTANT NOTE:

- **ADOBE ACROBAT READER (FREE SOFTWARE)** is recommended to open and print the patterns

link for free download

<https://get.adobe.com/reader>



x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x

x



x

x

x

Simple Messenger Bag : Pillow M
Mss S01 #4mm.
Main Body : Front & Back / Layout
1.8 mm. REC (max)

TILE TO PAGE 2








ack / Layout


g : Pillow M

Pattern






Belt Buckle area on body



Belt Strap on flap



CraftsmanGus : Pattern
D-Ring Holder
1.8 mm. REC

CraftsmanGus : Pattern

Barrel Messenger Bag : Gallon M

Mss G01 #4mm.


Back Pocket

1.8 mm. REC

X 1



TILE TO PAGE 5




			CraftsmanGus : Pattern Simple Messenger Bag : Pillow M Mss S01 #4mm. Strap 1.8-2.5 mm. REC X 1 Can adjust about to
--	--	--	--

		CraftsmanGus : Pattern Simple Messenger Bag : Pillow M Mss S01 #4mm. Strap 1.8-2.5 mm. REC X 1 Can adjust about to
--	--	--


			CraftsmanGus : Pattern Simple Messenger Bag : Pillow M Mss S01 #4mm. Front Opening Interfacing 1.8 mm. REC X 2 * t
--	--	--	--

* this back side of stitching may varies





TILE TO PAGE 4



manGus : Pattern

Messenger Bag : Pillow M

Mss S01 #4mm.

Strap

1.8-2.5 mm. REC

X 1

Can adjust about to 20-35 cm. +/- per fav.



manGus : Pattern

Messenger Bag : Pillow M

Mss S01 #4mm.

Strap

1.8-2.5 mm. REC

X 1

Can adjust about to 90-120 cm. +/- per fav.

CraftsmanGus : Pattern

Simple Messenger Bag : Pillow M


Mss S01 #4mm.


Front Opening Interfacing

1.8 mm. REC

X 2

* this back side of stitching may varies





CraftsmanGus : Pattern


Simple Messenger Bag : Pillow M




Ms S01 #4mm.

Main Body : Front & Back / Layout

1.8 mm. REC

* Can manage to make 2 piece combined (s








TILE TO PAGE 6

tern



M

out

combined (stitch) together.







bottom, if use 2 pieces of leather)



Overlapping area of the gusset. / (bottom, if use 2 pieces)

TILE TO PAGE 9





om, if use 2 pieces of leather)

TILE TO PAGE 8

